

## ASTON AVIATION INVENTORY LISTING

PART NO.	DESCRIPTION	SERIAL NO.	COND.	QTY
055916-04	FILTER ELEMENT ASSY	-	NW	14
071-01549-0200	ANTENNA ARRAY	3710	NW	1
327	LAMP		NW	1
10060	PRESSURE SWITCH	103	NS	1
11983	VALVE SOLENOID	KD006	NW	1
17903	SPRING		NW	8
42553	SPRING		NW	1
42554	SPRING		NW	5
42555	PISTON		NW	3
42556	SPRING		NW	7
42558	S/S ASSY	VARIOUS	NW	4
42567	STOP	VARIOUS	NW	3
42571	SPRING		NW	6
42572	PLUG		NW	8
42577	POPPET		NW	4
42581	CAP		NW	2
42584	SLD SLEEVE		NW	1
42597	SHIM		NW	10
42610	POPPET		NW	1
71540	VALVE	H612G	OHC	1
71541	VALVE CONTROL	180H	OHC	1
71544	SELECTOR VALVE	108G	NW	1
76016	RING RETAINER		NW	6
76324	LOCK PLATE		NW	6
83703	STEM FLUID		NW	1
8J703	CONTROL		OHC	1
100592	CAP		NW	4
100624	NUT LOCK		NW	13
100640	CLIP		NW	6
100647	RING SEAL		NW	8
100679	CYLINDER		NW	1
100820	RETAINER		NW	8
100970-1	NAME PLATE		NW	7
100973	SPRING		NW	4
100997	KIT		NW	1
103100	AUX DOOR ACT	2081A , 2082A	NW	2
103401	PLUG		NW	2
10391B	CUSHION EAR		NW	20
105885	NUT		NW	6
105886	SEAL		NW	2
1539910	FUEL PUMP		NW	1
14-60221-3	CHASSIS		NW	6
14-60247-3	CHASSIS		NEW	6
150SG122Q	STARTER GENERATOR	S00222XL2	OHC	1

0111341	PACKING		NW	9
187159	DETECTOR CHIP HELILOCK		NW	5
243196	BULB		NW	120
313012	PAD WEAR		NW	388
350903	PACKING		NW	2
410241	SEAL		NW	2
410910	TEMP SENSOR		NW	2
411612	RETAINER		NW	16
411706	SEAL		NW	2
503519	SCREW		NW	18
533400	LIFTER ASSY		NS	12
533589	VALVE ASSY		NEW	4
536556	ELBOW		NS	2
538209	GEAR DRIVER		NW	1
656767	COMPENSATOR	2124868	NW	1
3016608	NUT		NW	20
3019536	VALVE		NW	10
3019949	RING		NW	20
3029266	COVER		NW	1
3311586	ACCUMULATOR	8672226	INSP	1
3311586	ACCUMULATOR	7690080	RP	1
3903576	LST,PT		NW	1
4001891	SCREW		NW	14
4002713	WASHER		NW	5
4015959	SCREW		NW	7
4025179	VALVE INTAKE		NS	2
4043027	K WASHER		NW	42
5001182	SPRING		NW	92
5658124	TACHOMETER		NS	1
6809089	9TH STAGE COMP BLADE		OHC	95
6809090	10TH STAGE COMP BLADE		OHC	13
6809093	13TH STAGE COMP BLADE		OHC	95
9533123	WHEEL, BRAKE PART		NW	24
9533593	BUSHING INLET		NW	2
9533594	ADAPTER		NW	6
9535675	SEAL		NW	24
23053176	BLEED VALVE	FF26815	TST	1
23073353	BLEED VALVE	FF57144	OHC	1
30000547	S/S ASSY		NW	2
30000672	CAP		NS	3
30000674	CAP		NS	3
30000675	SPRING		NS/NW	5
30000694	NUT		NS	3
30006786	CRANK , INPUT		NW	5
30006971	COVER STOP		NW	6
30055114	SCREW		NW	13
30402104	FIRE EXTINGUISHER	28778-B1	SVC	1

42576	SEAT		OHC	1
4100012	BUSHING		NW	1
4100023	BOLT		NW	6
4100048	NUT		NW	27
4100074	BUSHING		NW	13
4100102	SCREW		NW	8
4100119	CAP		NW	3
4100218	PISTON	DMG2- 022 , 028 , 027 , 029 , 030 , 031	NEWLY INSP	6
4100226	S/S ASSY		NW	1
4100253	CLIP		NW	10
4100259	BUSHING		NW	1
4100262	SCREW		NW	3
4100263	WIRE DRIVE		NW	6
4100265	LEVER		NW	5
4100306	BOOT		NW	9
4100337	SCREW		NW	6
4100342	RETAINER		NS	3
4100363	BUSHING		NW	10
4100364	SUPPORT ASSY		NW	1
4100365	SEAT		NW	5
4100377	S/S ASSY		NS	1
4100389	I.D. PLATE		NW	2
4100399	ROD END		NS	2
4100404	BUSHING INPUT		NW	2
4100407	LINK		NW	6
4100408	HOUSING	2550, 2532, 4975	NS	3
4100417	RETAINER		NW	3
4100419	SPOOL & SLEEVE		NW	2
4100422	SPOOL & SLEEVE		NS	3
4100423	SLEEVE		NS	3
4100424	TRUNNION ASSY	2532 , 4975	NS	3
4100426	BUSHING		NW	4
4100455	BOLT, SHOULDER		NW	2
4100467	SPACER		NW	5
4100478	SPOOL & SLEEVE	D2796,D2797,D2799	NW	3
4100494	RETAINER		NW	2
4100515	PISTON	278-013	NEW	1
4100516	RETAINER		NW	2
4100528	BOLT		NW	21
4100563	SPRING		NS	3
4100564	HOUSING	152-004	NW	1
4100614	BUSHING		NW	3
4100615	PLATE RETAINER		NW	6
4100636	HOUSING ASSY , UPPER	69022 , VARIOUS	NW	5
4100628	BOLT		NW	6
4100667	PLUG		NW	1
4100669	SHIM		NW	6

4100692	BUSHING		NW	16
4100693	BUSHING		NW	2
4100722	SPRING		NW	8
4100733	SPACER		NW	2
4100738	PLUG		NW	8
4100746	I.D. PLATE		NW	1
4100747	SPRING		NS	6
4100748	SCREW , PLUG		NW	10
4100749	SPACER		NW	2
4100858	GLAND		NW	17
4100863	CAP		NW	7
4100864	CYLINDER		NW	2
4100877	CAP		NW	1
4100878	PLATE IDENTIFICATION		NW	19
4100898	CYLINDER		NW	1
4100918	SPRING		NW	4
4100919	SPRING		NW	4
4100927	GLAND		NW	7
41001023	WASHER		NW	6
41001029	SHIM		NW	3
41001057	SEAT		NW	4
41001158	SHIM		NW	1
41001386	WASHER		NW	20
41001466	RETAINER		NW	4
41001469	UPPER PISTON		NW	2
41001507	GASKET		NW	64
41001526	PIN		NW	5
41001668	S/S ASSY	878	NW	1
41001672	TUBE WIRE		NW	4
41001673	I.D. PLATE		NW	3
41001682	S/S ASSY		NW	3
41001688	I.D. PLATE		NW	5
41001728	POPPET		NW	10
41001842	WIRE DRIVE		NW	4
41001881	ROD INPUT / WIRE DRIVE		NW	2
41002409	SCREW		NW	40
41002429	PLUG RETAINING		NW	2
41002499	SHIM		NW	7
41002516	BEARING		NW	2
41002517	WASHER		NW	508
41002617	RING		NW	10
41002633	I.D. PLATE		NW	10
41002803	PLUNGER		NW/NS	4
41002804	CAP		NW	4
41002811	I.D. PLATE		NW	2
41002874	GUIDE, CHECK VALVE		NW	1
41002925	RETAINER SCRAPER		NW	5

41002939	PISTON POPPET		NW	3
41002941	BACK-UP		NW	148
41003203	HOUSING	VT34-175	NEW	1
41003225	CAP		NW	1
41003268	BOLT		NW	2
41003942	RETAINER		NW	4
41004237	GLAND		NW	2
41004373	RETAINER		NW	1
41004683	CYLINDER	235-014,279-002	NW	2
41004702	BUSHING		NW	6
41004852	BUSHING		NW	14
41005013	BUSHING		NW	4
41005085	WASHER		NW	8
4100523VA	LINK, IDLER		NW	1
41005371	NAME PLATE		NW	4
41005502	KEY		NW	75
41005581	SCREW		NW	9
41006106	GLAND		NW	2
41006472	CYLINDER		NW	1
41101004	GLAND		NW	2
41101006	RETAINER		NW	23
41101007	CAP		NW	1
41101009	I.D. PLATE		NW	3
48088837	SPRING		NW	4
48088855	NAME PLATE		NW	3
48088903	SHIM		NW	10
48088919	GASKET		NW	6
48088996	NAME PLATE		NW	10
663007005	PITCH CONTROL UNIT	DAP0087	REP	1
0102KPU2	PROCESSOR UNIT	XD9062 (Tag dd. 3/7/08)	INSP	1
035184	BLOWER FAN	EH3454	RP	1
047-620-694-007/012	SHOE ASSY		NW	1
06-1145	RESCUE KNIFE		NS	2
066-1101-00	NAV RECEIVER	3285	OHC	1
066-1101-31	NAV RECEIVER	M10134	RP	1
071-01550-0101	RADAR ANTENNA	1120	RP	1
100-024-1	NAME PLATE		NW	2
100-055-5 (204-030-931-005)	SHIM PLATE		NW	6
100-256-8873	SEAL STARTER MOTOR		NW	2
100648-1	CAP SEAL		NW	5
10-400615	CAPACITOR 400 VDC		NW	10
101707-3	POLE ASSY		NW	2
10181N01R00	RPM INDICATOR	599,446A	RP/TST/INSP	2
1-030-265-01B	OUTPUT PLUG		NW	49
10810-1	VANE AXIAL FAN ASSY	41	OHC	1
10900-7	ACTUATOR	08L	OHC	1
110753-1	DIAPHRAGM		NW	4

11-10899	FILTER HYDRAULIC	6144	OHC	1
120-008-C13-0	SHIM		NW	10
120-008C24E16	SHIM		NW	50
120-008C58E29	SHIM		NW	50
120-008-C28E20	SHIM		NW	50
120-043-32-24	SHIM		NW	2
120-045-31-12	SHIM		NW	3
120-046-31-20	SHIM		NW	3
120-06014-0001	IC (LSCL4023ABC+)		NW	1
120-079-8-8	SCREW		NW	1
124-987-2	INDICATOR ASSY	80M0128	OHC	1
13034 (Alt: 1680-00-969-9157)	STERN VALVE		NS	9
140GA01Y02	CONTROL BOX	1198	RP	1
14141-0345-1154	NAV MANAGEMENT UNIT	1327	RP	1
14-27226-26	COVER		NW	2
14-60321-501	RELAY ASSY	22652-101 to 103	NW	3
14-60322-507	RELAY ASSY (3438RH)	22652-101 to 22652-106	NW	6
14-60323-514	RELAY 3439	22652-101 to 105	NW	5
14-60323-514	RELAY 3439	22652-106	NW	1
1466-5W	PIN		NW	21
1496-3W	PIN		NW	20
BA4943	APU DUCT		SVC	2
1604-129Y	PLUG		NW	47
16270-0101-06	GNS-X CDU	112,554	RP	2
17018-0005	INDICATOR		OHC	25
96774-18-1814	TORQUE TRANSMITTER PRESS	4237 , 4110	OHC	2
1B250-B212-1661	INVERTER	T11128168,T11128167	NW	2
200037-22	INSERT		NW	4
200037-3	INSERT		NW	2
200-1740-000	MOUNT RESILIENT		NW	40
200-1740-000	MOUNT RESILIENT		NW	10
2004T64P02	SCREW		NW	65
200SGL132Q (206-062-200-123)	STARTER GENERATOR	4603XL2	OHC	1
20-057-4-34	BOLT		NW	20
20-057-5-27D	BOLT		NW	4
20-057-5-52D	BOLT		NW	2
20-065H10050	BOLT		NW	6
20-065H10052	BOLT		NW	4
14-50175-9	SHIELD		NW	2
2022550-5-3	TMS LINEAR ACTUATOR	108-1029	RP	1
204-010-433-033	LINER		NW	3
204-011-108-117/009	BUFFER		NW	30
204-011-119-001	BEARING		NW	6
204-011-329-001	CABLE ASSY		NW	6
204-012-118-001	SHIELD		NW	20
204-030-619-145	SKIN		NW	1
204-030-619-146	SKIN		NW	1

204-030-619-147	DOUBLE R/H		NW	1
204-030-619-148	DOUBLE		NW	1
204-030-619-149	BRACKET		NW	1
204-030-619-150	BRACKET		NW	1
204-030-619-151	CLIP		NW	1
204-030-619-153	FILTER		NW	2
204-030-619-155	CLIP		NW	1
204-030-619-156	CLIP		NW	1
204-030-930-013	BUSHING		NW	4
204-031-920-003	DAMPER	PA-18	NS	1
204-040-413-001	CLIP		NW	1
204-040-603-009	COUPLING		NW	7
204-040-611-001	SEAL		NW	15
204-050-155-005	RAM ASSY		NW	6
204-070-907-101	ELECTRIC MOTOR	1104	NW	1
204-076-162-001	BUSHING (PAIR)		NW	1
204-076-171-1	BOOT		NW	50
204-076-201-005	BRACKET MOUNT		OHC	1
205-001-735-001/60-006-13	GUIDE		NW	10
205-001-735-003/60-006-3	GUIDE		NW	10
205-030-007-166	STIFFENER		NS	1
205-030-163-93	HANDLE DOOR (CAP)		NW	2
205-030-163-121	ATTACHMENT		NW	1
205-030-164-121	ATTACHMENT		NW	1
205-030-164-229	CAP		NW	1
205-030-712-039S	ANGLE ATTACHING		NW	1
205-030-712-045S	ANGLE ATTACHING		NW	1
205-030-712-103S	ANGLE ATTACHING		NW	1
205-030-712-167S	ANGLE ATTACHING		NW	1
205-030-713-14	BRACKET		NS	2
205-030-889-039S	RIB		NW	2
205-030-889-040S	RIB		NW	2
205-031-432-152	COVER, ACCESS R/H		NW	1
205-031-436-001	SUPPORT		NW	1
205-031-502-001	HINGE		NW	5
205-031-502-002	HINGE		NW	5
205-031-504-002	HINGE ASSY		NW	5
205-032-173-001	ROD ASSY		NW	2
205-032-669-126B	TRACK		NW	1
212-001-057-001	TUBE		NW	1
205-032-820-007	STIFFENER		NW	1
205-032-820-009S	STIFFENER		NW	1
205-032-820-031	BULKHEAD ASSY		NW	1
205-032-821-021	BULKHEAD ASSY		NW	2
205-032-821-023	BULKHEAD ASSY		NW	1
205-076-044-007 (15082-7)	HYD. PRESS SWITCH	1840,1902,6090	NW	3
205-076-386-1	DECAL		NW	5

206-001-053-001	BEARING		NS	5
206-010-421-003	BUSHING		NW	3
206-011-812-005	TRUNNION		NW	2
206-031-501-097	SEAL		NW	6
206-076-062-101FM	Servo	RH2162A	OHC	1
206-076-062-123	SERVO	HR960	OHC	1
3311222-1	DUCT ASSY		NW	1
206-285-100	MOTOR	5562	SVC	1
206-351-0008	FUEL PRESSURE	330	NW	1
206-373-901-103	VALVE	488 & 505	OHC	2
206-375-005-101	TOT INDICATOR	02031518EA	NW	1
2067568-0501	RADAR ANTENNA	1168	OHC	1
209-062-003-001	SWITCH	25,209	NW	1
209-070-262-105 / 124-013-4	TEMP & PRESSURE INDICATOR	98020085	RP	1
209-076-043-105	BUSHING		NW	2
205-076-034-7 (PTI-05228-21-11655)	FILTER		NS	1
2117404-5	CONTROLLER APU	46-1051 (Tag dd. 16/4/08)	MOD	1
2117578-9	CONTROLLER ASSY	22-B0003 (Tag dd. 28/9/09)	RP	1
2118480-1	CONTROLLER CABIN	85-416	RP	1
212-001-056-001	TUBE ASSY		NW	2
212-001-057-001	TUBE		NW	1
212-001-321-001	ARM ASSY / LEVER		NW	1
212-010-306-001	WEIGHT		NW	4
212-010-729-003	BUSHING		NW	20
212-030-100-023	SKIN L/H		NW	1
212-030-100-024	SIDE SKIN R/H		NW	2
212-030-100-025S	SKIN UPPER AFT		NW	2
212-030-132-051S	LONGERON		NW	1
212-030-132-065A	LONGERON		NW	1
212-030-132-150B	LONGERON		NW	1
212-030-132-153B	LONGERON		NW	1
212-030-132-155S	SPLICE L/H		NW	1
212-030-132-159S	SPLICE		NW	1
212-030-145-017	STRINGER		NW	2
212-030-158-001P	FITTING R/H/ UPPER		NW	1
212-030-161-001	FITTING		NW	1
212-030-156-047S	BULKHEAD		NW	1
212-030-502-101P	FITTING		NW	1
212-040-125-101	WASHER		NW	10
212-030-160-001	FITTING		NW	1
212-061-101-001	BEARING		NW	2
212-061-112-001	BUSHING		NW	4
212-061-903-135	GASKET		NW	4
212-070-116-005	INDICATOR	93080083 , 97030358 , 97060360	RP/NW	3
212-070-182-001	HYD. PRESS IND.	SD064,SD098	NW	2
212-070-241-001	TEMP INDICATOR	76D6485 & 7347763	INSP	2
212-073-916-001	FLOAT SWITCH	10724U, 10717U, 14998U, 14906U	NW	4



212-076-116-103	BRACKET		NW	2
212-076-120-001	NUT		NW	2
212-076-121-007	DECAL		NW	2
212-076-121-009	DECAL		NW	12
212-076-121-011	DECAL		NW	17
212-076-121-101	DECAL		NW	15
212-076-121-105	DECAL		NW	10
212-076-121-111	DECAL	-	NW	3
214-001-094-001	BOOT		NW	9
214-010-856-103	BEARING		NW	51
214-011-809-109	STOP		NW	3
214-031-012-105	WINDSHIELD ASSY		NW	4
214-031-012-106	WINDSHIELD ASSY		NW	4
214-040-192-003	COVER		NW	3
214-040-664-101	FILTER ELEMENT		NW	10
214-040-814-105	SLEEVE		NW	6
214-040-841-101	SEAL		NW	10
214-040-853-101	SEAL		NW	10
214-040-910-101	BEARING	ZV-6246 & ZV-6258	NW	2
214-040-936-105	ADAPTER ASSY		NW	1
214-060-056-003 (2CM272B1)	STARTER GENERATOR	82M0063	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	85E 0198	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	87D0339	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	94A 1241	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	81M0020	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	94C1260	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	90B0852	OHC	1
214-060-056-103 (2CM272B1)	STARTER GENERATOR	02K1426	NW	1
214-075-244-101	RATE GYRO	3073-15	INSP	1
214-076-033-1	PUMP HYDRAULIC	AU30-13990A	OHC	1
214-076-104-001	BEARING		NW	2
214-076-294-101	ACTUATOR	HR 0150,028	OHC	2
214-076-294-101	ACTUATOR	55	OHC	1
214-076-297-101	BOOT		NW	12
214-076-559-101	WASHER		NW	2
214-077-253-101	CONNECTING MOUNTING PLATE		NW	3
214-175-155-103	RELAY	AP-1993	NW	1
214-175-248-103	GAS TEMPERATURE INDICATOR	102	OHC	1
214C50-52	SWITCH	J332	NW	1
2-131-159-01	WASHER		NW	5
2-160-010-20	STARTER GENERATOR	14968	OHC	1
2-160-350-40	AIR BLEED ACTUATOR	94C005	OHC	1
21Y37A	JACKING PAD REAR		NW	1
2-303-431-02	FILTER		NS	1
2-303-766-01	LEAD IGNITION	196 , 206	SVC	2
2-303-767-02	LEAD IGNITION		SVC	2
2-303-769-03	LEAD IGNITION	56971100191	SVC	1

23-101	CONTROL BOX	348	RP	1
23-102A	CONTROL BOX	1	RP	1
101-00212	PRESSURE TESTER	3575, 4655	NW	2
23491	BATTERY	E00297	OHC	1
235-1057-16	DUCT ASSY		NW	4
2-40134-1	SPINDLE, M.H.BAR		NW	20
250SG112Q	STARTER GENERATOR	2054	OHC	1
2524998-14	MANUAL F.C.U.	A15741	OHC	1
2566A-25	SENSOR	302-1	OHC	1
2587193-43	DIRECTIONAL GYRO	81054920	OHC	1
2600/05.1	ELECT. CLOCK	1535	INSP	1
261151-19	GASKET		NW	7
2722371-2	SEAL		NW	11
2803W359L5A	INDICATOR SYMBOL		NW	1
2LS426-T6-4W	PIN		NW	12
30000556-001	PIN		NW	4
30-015-5	NUT		NW	21
30-326ET-1	CONTROL AMPLIFIER	904	NW	1
303801-1/ALT 305518-1	CONTROL SIGNAL ASSY	P-3732,P-3771,P-3740,P-3753,P-3754,	NW	5
304-00104	GAUGE ( 0-600 PSI )	BA9329	NW	1
304-00102	PRESSURE GAUGE	BB2788	NW	1
3050264-02	CHIP DETECTOR		NW	15
3101-08	FIRE DETECTOR COWL	2482	INSP	1
3101-09	FIRE DETECTOR ENGINE	12981	INSP	1
3130566-20-012	SHIM		NW	1
3-13555-1	SWITCH		NW	1
31-6498-3	LAMP ASSY		NW	1
3180131-2	ACCUMULATOR ASSY	3630 & 3662	RP	2
3203066-00	UPPER CD		NW	2
321EDP3-2	PRIMARY ENGINE DISPLAY	AC110-080 (Tag dd. 28/6/07)	RP	1
3244706-6	CONTROL, TORQUE	A8469	OHC	1
3244708-1	MIN PRESS VALVE	A88030	OHC	1
3244736-8	MANUAL F.C.U.	A15754	OHC	1
3244736-8	MANUAL F.C.U.	A86844	OHC	1
354434-3	SHAFT ASSY		NW	1
3567401-3001 (130-020-3)	OIL PRESS TRANS Ty Tru-66A	51637	NW	1
3571212-3005	PRESSURE INDICATOR	8808104	OHC	1
371353-667	TUBE ASSY		NW	3
372602-3	PLATE		NW	8
372602-4	PLATE		NW	8
373326-3	SEAL DOOR ACCESS		NW	1
373965-1	BUSHING		NW	3
37B202173P108	TURNBUCKLE		NW	11
3882600-8-1	FUEL CONTROL UNIT	A698C (Tag dd. 29/8/06)	INSP	1
38E63-12C	VALVE	RF-1155 / RF-1261	RP	2
392530-1-1	REGULATOR VALVE	P-3470	OHC	1
393084-22825	FUEL QTY IND.	M783F	NW	1

400-003-4490-91	BONDED SEAL		NW	1
400-008-4490-41	BONDED SEAL		NW	3
400-306-4490-91	BONDED SEAL		NW	1
40-0023-1	FLASHER UNIT	427	TST	1
400-510-4490-41	BONDED SEAL		NW	1
4014692CL1	WEIGHT, CTERBALANCE		NW	24
4014693CL1	COUNTER WEIGHT		NW	29
4018369-905	Flight Director Computer	92096704	OHC	1
4056510-903	DISPLAY	96103421	OHC	1
4066300-901	SYMBOL GENERATOR	91040259	RP	1
40E17-1B	VOLTAGE REGULATOR	R37735,R39861,R37048,R35847,R38382,R38011	OHC	6
41000074-001	BUSHING		NW	5
41000284-002	BEARING		NW	2
41000286	HOUSING		NS	20
41000355-002	BUSHING		NW	12
41000515VA	PISTON	VA-0048	NEW	1
41000564AA	HOUSING ASSY	10Z21-044	NEW	1
41000589VA	PISTON	VA-0019	NEW	1
41000643	PISTON	303-031	NW	1
41000643VA	PISTON	VA-0106	NEW	1
41000646-002	CYLINDER	E1219	NW	1
41000756-1	REPAIR KIT	VARIOUS	NW	9
41000898AA	CYLINDER	10302-041	NEW	1
41001662-001	SHIM		NW	9
41001756-001	SHIM		NW	1
41001756-003	SHIM		NW	1
41001756-004	SHIM		NW	1
41001756-005	SHIM		NW	7
41001759-001	SHIM		NW	7
41001759-005	SHIM		NW	4
41001216-017	ID PLATE		NW	1
41002499-001	SHIM		NW	5
41002499-004	SHIM		NW	5
41002502-002	SHIM		NW	8
41002926-001	STOP		NW	8
41003203AA	HOUSING	10020-052	NW	1
41003367-002	SHIM		NW	14
41004577AA	CYLINDER	10026-018	NW	1
41004683AA	CYLINDER	10138-014	NW	1
41004687AA	CYLINDER	1126630	NW	1
41004693VA	MOUNTING CAP	VA-L788	NW	1
41004704-001	CAP		NW	1
41004704-001VA	CAP, END	VAL-L585	NW	1
41004852-002	BUSHING		NW	2
41005826AA	BOLT		NW	1
41006472AA	CYLINDER	10246-081	NW	1
4103650009	HYDRAULIC SERVO	318	NW	1

41100334-001	SHIM		NW	4
41100363-001	SHIM		NW	26
41100363-002	SHIM		NW	8
41100363-003	SHIM		NW	10
41103650-007	PLATE		NW	2
41103750-017	SERVO ASSY	2972	OHC	1
412-040-002-109	TRANSMISSION ASSY	A-63	OHC	1
412-076-620-101	UNIVERSAL	2267	NW	1
412-240-009-103	BEARING		NW	1
417-00102-004	COMPUTER	124	RP	1
417-00104-003	AUTO PILOT CONTROL	140	RP	1
42575-2	RET		NW	4
42595-3	BODY		NW	2
4259-20	COUPLING TOILET		SVC	1
42C42641-1	HDY SERVO	RHO355	OHC	1
42C42641-03	HDY SERVO	RHO353	NW	1
4344EA-3	FLAP SREW JACK	1005	RP	1
4502996B	FUEL CONTROL ASSY	12C96-59 (Tag dd. 14/9/09)	RP	1
450-191	MASK		NW	9
450-75-512SH	CLAMP		NW	4
454-00188-002	VERTICAL GYRO	234	OHC	1
45900-1	ANTI-COLLISION LIGHT ( NAV )	CA3849	TESTED	1
978560-2-1	VALVE	P199	OHC	1
460004782C	WRENCH MAIN WHEEL		NW	1
46004716C	WRENCH NOSE WHEEL		NW	1
461-00320-100	DIRECTIONAL GYRO	361	OHC	1
47-140-125-003	TUBE STABLIZER		NW	1
47-140-252-003	BEARING		NW	16
47-612-152-001	PIN TRUNNION		NW	2
47-620-692-001	PIN		NW	2
47-620-693-001	BUSHING		NW	4
4-76061-7	CLEVIS ASSY, TOW BAR		NW	3
48088848-7	I.D. PLATE		NW	1
48088996-001	I.D. PLATE		NW	40
48351-101-0	AUDIBLE WARNING UNIT	1020 (Tag dd. 4/12/08)	INSP	1
4X	PLUG		NW	11
50011LL-1	MULTI DISC BRAKE	MAR74-347, MAR74-349	NW	2
5003096-6	BRAKE ASSY	JUN88-827, MAR01-5787	OHC	2
50-810351	RING BEARING		NW	1
51-12B	AMPLIFIER	384	RP	1
S11498-1	SEAL, CANOPY		NW	6
511846-4	WASHER BLEEDER		NW	6
522-1836-000	ADF RECEIVER	3037	OHC	1
522-3443-001	ANTENNA COUPLER	9502	OHC	1
522-3443-000 (001)	ANTENNA COUPLER	9572	RP	1
522-3443-000	ANTENNA COUPLER	10810	RP	1
523SUE3	YAW COMPUTER	1311	OHC	1

5392-16	SCREW		NW	8
548404-3-1	TEMP. CONTROL	069C-134	OHC	1
55-0283-3	FLASHTUBE BEACON		INSP	2
55-0331-3	FILAMENT		NW	2
568-1-25663-001	HYDRAULIC FUEL PUMP	143	INSP	1
5331-01-005-0514	O RING		NW	8
5701C000-003	TEMPERATURE SENSOR	722137-6 (Tag dd. 2/7/08)	INSP	1
5X	PLUG		NW	11
620359	FLUX VALVE	8105439	NW	1
6029T27G03	OIL JET		NW	4
612-1-43530-103	DATA ACQUISITION UNIT	10105 (Tag dd. 6/11/06)	RP	1
6135-00-838-0706	N R BATTERY (BA1568-U)		NW	13
622-3371-001	HF RECEIVER	2,657	RP	1
622-3856-001	ADF RECEIVER	969	RP	1
622-3890-002	RADALT TRANSCEIVER	7393	RP	1
622-5139-001	INDICATOR	9	OHC	1
622-7878-201	TRANSPONDER	1637 (Tag dd. 7/7/08)	INSP	1
62C40837-15	THERMOSTAT		NW	4
630-3-250	D-D SEAL		NW	1
633294-1 / 633217-1	FLEXIBLE WAVE GUIDE	068 - 074	NW	7
6-41641-1	PIN		NW	8
6-42301-501	RING SLOT CANOPY	3148	NW	1
6-42301-501	RING SLOT CANOPY	3095	NW	1
6-42301-501	RING SLOT CANOPY	3217	NW	1
6-42301-501	RING SLOT CANOPY	2,693	NW	1
6-50327-511	VALVE , DIVERTER	117031-101	NW	1
6-50532-5	TUBE ASSY		NW	2
6643-005-00BJ (666-000-143)	PROPELLER ELECTRONIC CONTROLLER	1242	RP	1
6809085P	5TH STAGE COMP BLADE		NW	82
ML6839	FILAMENT		NW	170
68D37158-7	MANIFOLD		NW	1
68D37158-9	MANIFOLD		NS	1
68E34402-10	WINDOW LIGHT ASSY	8X897	NW	1
7006	SKYDROL RE-OILING PUMP	13/255/1	NW	1
7007	SKYDROL RE-OILING PUMP	13/254/2	NW	1
70-010J000A136	HOSE		NW	4
70-010K000A116	HOSE		NW	4
70-010L000X140	HOSE		NW	1
70-0100L000X174	HOSE		NW	1
70-0705-4436-9	3M SAFETY-WALK SLIP RESISTANT MATERIALS		NW	2
700-1-22490-520	GENERATOR CONTROL UNIT	TE1802	INSP	1
700-1-22490-420	GENERATOR CONTROL UNIT	TE0627	INSP	1
701575-1	TUBE ASSY		NW	60
705-15V4	HORIZON GYRO	18627	OHC	1
7117MR972P4	SEAL		NW	40
711A3MR-160T	PISTON RING		NW	13
7142705-30	JACKET ASSY		NW	2

7212MR-972-P4	PACKING		NW	4
721A6MS987P4	SEAL		NW	2
72428	VALVE	H395G	OHC	1
732224-1	PIN		NW	15
733-201-20	BALLAST UNIT 3000AN	1149, 1152	RP	2
740518C	GPCU	375	RP	1
741SUE3	YAW COMPUTER	1120 (Tag dd. 13/11/09)	INSP	1
741SUE3	YAW COMPUTER	1337 (Tag dd. 13/11/09)	REP	1
74-661-041-11M	BELT SET	1920 & 2178	NW	2
7585392AM	FILTER ELEMENT		NW	3
05228-7585394AM	ELEMENT HYDRAULIC		NW	3
7-60321-501	RELAY ASSY ELECT	22654-102	NW	1
7-60322-1	RELAY ASSY ELECT	22654-101	NW	1
7-60324-501	RELAY	22654-101	NW	1
778727-8	TEMP CONTROL VALVE	910762	RP	1
785-079	LOW FLOW SENSOR DETECTOR	854	RP	1
7874A7	ARGON CYLINDER		NW	2
EVT1347B	RECIRCULATION FAN	416	RP	1
792-6091-011	H.S.I. INDICATOR	3114	OHC	1
79D4684-3	LENS VISOR		NW	8
7G74	SWITCH	747	NW	1
80093-13	O-RING		NW	1
8-060-03	PCB		SVC	4
82005527-005	PACKING		NW	40
82006007-002	PACKING		NW	2
84002887-117 / S30772-117G20N	SEAL PLUS II ASSY		NW	9
8530819 / 510819	INLET PLUG		NW	2
88611-4	I.D. PLATE		NW	1
8870-K3 / M8805-55-002	FOOT SWITCH		NW	7
895951-1	TRANSDUCER	2709/2684/2702/2310/2649/2680	NW	6
9025-114	SEAL		NW	11
920-4-50CS	SCALE, WEIGHING KIT	1542400084	NS	2
9207-10296	RELAY	2432	INSP	1
93A151-20	CONTROL UNIT	73165 (Tag. 8/7/08)	INSP	1
980-4100-FWXS	DIGITAL FLIGHT DATA RECORDER	1635	OHC	1
980-4100-DXUS	FLIGHT DATA RECORDER	7923	INSP	1
980-6005-055	COCKPIT VOICE RECORDER	7479	OHC	1
981-6009-010	FLIGHT DATA RECORDER	2546	RP	1
995-9121	FILAMENT		NS	1
A102-16E	BOLT		NW	13
A218-957568-00	GRIP ASSY	VARIOUS, 0005, 0004	NW	10
A25-8C	BOLT		NS	25
A31-1 ROJ	RESISTOR		NS	40
A7632	GASKET	acc for tail nav 3-6468-5	NW	1
A7635A5	RETAINER BAND GASKET	acc for tail nav 3-6468-5	NW	1
ABC-5748	BOLT		NW	6
ABC-6095	BUSHING		NW	3

AB205-050-400-055	CROSSTUBE	AB0134 & AB0123	NW	2
AB205-050-400-063	CROSSTUBE ASSY	CF0004	NW	1
AC67726	BRAKE CONTROLVALVE	KN300	RP	1
AC67728	BRAKE CONTROL VALVE	HC419	RP	1
AH43941	IB HALF HUB	67	OHC	1
AHM9053	BRAKE ROTOR SEGMENT		NW	1
AN174-24A	BOLT		NW	6
AN101129	BOLT		NW	40
AN316C6R	NUT		NW	23
AN320-8	NUT		NW	4
AN3-12A	BOLT		NW	21
AN386-1-10A	PIN		NW	2
AN3-8A	BOLT		NW	58
AN5540-2	THERMO COUPLER		NS	1
AN6204-1	VALVE		NW	6
AN804-5C	UNION		NW	4
AN8-21	BOLT		NW	3
AN815-4J	UNION		NW	5
AN960-616	WASHER		NW	50
AN960B716	WASHER		NW	10
AS1038J0606	ELBOW		NW	2
AS1895-7-350	SEAL		NW	10
AS2230-308	RIVET		NW	1000
AS3492-01	SEAL		NW	10
B7633-1	GASKET		NW	1
B7669B	CHIP DETECTOR		NW	1
B345LS / SA161	EXY POWER/APU LINE CONTACTOR	CJ-83607	INSP	1
BE12964 / 130743	CORRUJOINT SEAL		NW	10
BE12965	CORRUJOINT SEAL		NW	10
BE20059	CORRUJOINT SEAL		NW	10
BE20061	CORRUJOINT SEAL		NW	10
BAS-212/412-1500SG	PRESSURE TRANSDUCER	6081-5-167	NEW	1
BAS-212/412-1500SG	PRESSURE TRANSDUCER	6292-11-288	NEW	1
BAS-212/412-1500SG	PRESSURE TRANSDUCER	6292-11-292	NEW	1
BAS-212/412-1500SG	PRESSURE TRANSDUCER	6292-11-270	NEW	1
BAS-212/412-1500SG	PRESSURE TRANSDUCER	6292-11-260	NW	1
BHL212-2671-001	INST OF WIRING LOOM		NW	2
BHL212-3469-001	BRACKET ASSY		NW	2
BHL212-3470-201	DOUBLE		NW	2
BHL212-3512-001	TOP HAT ASSY		NW	2
BHL212-3513-201	DOUBLE		NW	2
BHL212-5170-001	FLOAT SWITCH GUARD		NW	4
BHL212-5170-002	FLOAT SWITCH GUARD		NW	4
C-17638-101	RESERVOIR & VALVE ASSY	199073 & 824519	OHC	2
C3317-020	ORING		NW	7
C360-026-0690	SPRING		NW	3
C-42641-12	S/S ASSY		NW	1

C42641-15	PISTON		NW	1
C42641-50	GUIDE		NW	1
C42641-54	BUSHING		NW	1
C42641-58	BUSHING		NS	1
C42641-59	JAM NUT		NW	1
C42641-70	CYLINDER		NW	1
C42641-81	PISTON		NW	1
C42641-88	GLAND		NW	1
C42641-90	LUG ASSY		NS	1
C42642-15	S/S ASSY		OHC	2
C42642-46	BUSHING		NW	3
C42642-48	BUSHING		NW	2
C5120-3	ENGINE STARTER MOTOR	296-C	RP	1
C6287 / ARC-51BX (522-3629-001)	RADIO SET CONTROL	51	NW	1
CB156-35	SEAL		NW	26
CEC401-112-01	SCRAPPER		NW	7
CEC401-216-01	SCRAPPER		NW	35
CEC4-2052-01	RETAINER		NW	5
CEC4-3299-01	PACKING & RETAINER		NW	5
CEC5091-0625-55	SCRAPPER		NW	1
CH34249	IGN PLUG		NW	2
CR3212-4-2	FASTENER		NW	49
D45297	POTENTIOMETER	04G00045	NS	1
DAS2064A4	SEAL BRAKE HOSE		NW	10
DMQ18-3	ELT ANTENNA	341B	-	1
DPXBMA4533S0201	ELE-CONN		NW	2
EAEDC 8407-411	ENGINE DE-ICING CONTROL UNIT	FBE0123	RP	1
E-311TS	RELAY	CJ90028	NW	1
EA470-3587	TANK UNIT	6599, 6614	NW	2
EA470B-3588	TANK UNIT	6109, 6116	NW	2
EADF18317-411	FUEL FLOW DISPLAY ASSY	FBE0085	RP	1
EH183308	NUT		NS	1
EH183903	AXLE SUB ASSY	DE7864	NW	1
EH183915	SPACER		NW	2
EU14476	VALVE		NW	4
EU15969	CORRUJOINT SEAL		NW	10
EU32738	SEAL		NW	14
F7941-032-401	SENSOR ASSY T.A.T.	5219CE	INSP	1
GPU 3000/80 (GPU1500/40)	POWERVAMP PORTABLE GROUND POWER		NW	1
GYS7N77	BOLT MACHINE		NW	50
GY18B10	RIVET		NW	320
GY18B11	RIVET		NW	100
GY18B-19 ALT#AB18B19H	RIVET TUBULAR		NW	52
GYR8A-18	RIVET		NW	300
H10-13.4	HEADSET		NW	3
H22241-12	INSERT HOUSING		NW	2
H51132-4K7 / NSA5474-4K7	NUT		NW	12



91547	BLADE VALVE	AAH021	SVC	1
H51132-3K7	NUT		NW	12
HC36100052-000	RING	GRNA96832	-	2
HC921H1837-000	JUNCTION BOX	GE002	-	1
HC923B0185-000	COVER		NW	2
HL13VAP5-8	HI-LOC		NW	1
HL186-6	HI-LOC		NS	24
HL3086W6-8	PIN / COLLAR		NS	100
J5736-13	MOUNT SPRANG		NW	4
J643P08A	BOLT		NW	4
K11508	RING / SEAL		NW	12
K11509	SEAL		NW	10
K11514	SEAL		NW	10
K11518	SEAL		NW	10
K11522	RING		NW	2
K11526	SEAL		NW	10
K11534	RING		NW	4
K11536	RING		NW	10
K11542	RING		NW	18
KB16236	RING		NW	20
KC410005707CO	REPAIR KIT		NW	2
KIN5213	HOLDER		NW	130
KR6-CN-001	BEARING		NW	3
LD1655801370-L275	SIGNAL SMOKE		NW	3
LL57J40P4	SCREW		NW	1
LL57J40P5	SCREW		NW	1
LM200-SA47	REAR MOUNT	RS8864E	OHC	1
LN9139-M5X14	SCREW		NW	15
LN9442-M5X8	SCREW		NW	20
LS35064A2C075	STANDOFF , THREADED		NW	20
LS35076-1-02	SPACER		NW	1
LS3850-2-12	SHIELD ASSY		NW	1
LS4634-6	PACKING (CURE DATE: 1Q06)		NW	1200
LCTC13968-X	HOIST		NW	1
LTCT14769	REMOVAL TOOL	S83L21	NS	1
M3863A / 989803136291	BATTERY		NW	1
M5501/7F10/T5	CAP PROTECT		NW	1
M6212	VALVE	1042	OHC	1
M6241	VALVE	3845	SVC	1
M83248/1-009	O RING		NW	120
M83248/1-141	PACKING		NW	66
M83248-1-012	PACKING		NW	10
M83248-1-014	PACKING		NW	10
M83248/1-128	PACKING		NW	15
M83248-1-018	PACKING		NW	10
M83248-1-138	PACKING		NW	14
M83248-1-261	PACKING		NW	9

M83248-1-902	SEAL O RING		NW	15
M83248-1-905	PACKING		NW	15
M83248-1-907	PACKING		NW	27
M83383/01-10	RCCB	53087	NW	1
M83461-1-011	PACKING		NW	11
M83461-1-115	PACKING		NW	8
CB24-3150	BATTERY		NW	2
MFFA 370/1	ELEMENT FILTER ASSY	067424 - 067434	NW	10
MI-585164-1	ANTENNA	1108	OHC	1
MPA 30502	W/W ELEMENT	-	NW	10
MS14104-6	BEARING		NW	4
MS14104-9	BEARING		NW	1
MS15001-4	FITTING		NW	25
MS16555-34	PIN		NW	37
MS20002C6	WASHER		NW	20
MS20006-12	BOLT INTERNAL		NW	100
MS20257-2	HINGE		NW	100
MS20470AD5	RIVET		NW	2902
MS20470DD5-16	RIVET		NS	10
MS20762-12	ELBOW		NW	4
MS20995C18555LB	LOCKING WIRE		NW	4
MS20995C25SS5LB	LOCKED WIRE		NW	4
MS21042L3	NUT		NW	90
MS21042L4	NUT		NW	84
MS21059L3K	NUT		NW	15
MS21086L4	NUTPLATE		NW	20
MS21289-08	BOLT MACHINE		NW	10
MS21919WDG12	CLAMP CUSHION		NW	10
MS22073-5	CIRCUIT BREAKER		NW	1
MS24356-2B	NOZZLE	0837K	OHC	1
MS24465-4	BEARING		NW	5
MS24540-2	CAGE OIL PRESSURE		NS	2
MS24665-151	COTTER PIN		NW	4
MS24665-155	COTTER PIN		NW	188
MS24665-162	COTTER PIN		NW	99
MS24665-285	COTTER PIN		NW	96
MS24665-302	COTTER PIN		NW	150
MS24694S105	BOLT		NW	75
MS25036-118	TERMINAL LUG		NW	2
MS25036-131 (YAEV1CL3)	TERMINAL LUG		NW	96
MS27039C1-09	SCREW		NW	25
MS27039-1-15	SCREW		NW	50
MS27212-3-1	TERMINAL		NW	5
MS27641-10	BEARING		NW	5
MS28773-04	RETAINER		NW	10
MS28773-08	RETAINER		NW	3
MS28775-223 / AN6230-B1	PACKING		NW	1

MS28775-230	PACKING		NW	1
MS28775-234	PACKING		NW	1
MS28775-235 / AN6230-13	PACKING		NW	2
MS28775-241	PACKING		NS	1
MS28775-254	PACKING		NW	2
MS28775-280	PACKING		NW	2
MS29512-12	PACKING		NW	40
MS3102R16S1P	CONNECTOR		NW	2
MS3116E14-5P	CONNECTOR		NW	6
MS3126E14-15S	CONNECTOR		NW	2
MS3456W12-3S	CONNECTOR		NW	6
MS35207-229	SCREW		NW	40
MS35266-61	SCREW		NW	25
MS51861-34	SCREW		NW	50
MS83248-1-128	PACKING		NW	15
MS9171-10	BOLT		NS	30
MS9371-16	GASKET		NW	2
MS9592-138	BRACKET		NW	17
MS9902-04	PLUG		NW	1
N142421	CLAMP		NS	3
NAS1149D0316J	FLAT WASHER		NW	199
NAS1149D0332J	WASHER		NW	148
NAS1149D0463J	WASHER		NW	188
NAS1149D0563J	WASHER		NW	44
NAS1149F0432P	WASHER		NW	50
NAS1149F0532P	WASHER		NW	100
NAS1149F0463P	WASHER		NW	336
NAS1149F0563P	WASHER		NW	73
NAS1149F0663P	WASHER FLAT		NW	190
AN960-416	WASHER		NW	95
NAS1197-10	WASHER		NW	150
NAS1352C08H6	SCREW		NS	6
NAS1612-6	PACKING		NW	2
NAS230-18	SCREW		NS	2
NAS43HT3-44	SPACER		NW	1
NAS4403-2	BOLT		NW	30
NAS509-8C	NUT		NW	10
NA S551-4DH	BOLT		NW	4
NAS5004-6	BOLT/SCREW		NW	10
NAS6603-7	BOLT		NW	60
NAS6605-11	BOLT		NW	20
NAS6604-10	BOLT		NW	14
NAS818N6	PLUG		NW	9
NF0075-1705	ICE DETECTOR ASSY	L206931	RP	1
NSA5474-3K7 / HS1132-3K7	NUT		NW	12
P0640-101	LIFE VEST		NW	10
P01074-101C	LIFE VEST		NW	18

P01074-101W	LIFE VEST		NW	115
PDCR330-2096	OIL PRESS TRANSDUCER	1031483	NW	1
PT08CP-18-325W351	CONNECTOR PLUG		NW	1
PW06E-20-39S ( 9606N29H8S )	CONNECTOR		NW	5
R1307P007	PACKING		NW	48
RB50A	POWER PACK		NW	1
R1307P008	PACKING		NW	49
RW41000478	SPOOL & SLEEVE	1-639, 969, 848, 227, 655, 965	INSP	6
RR50S	RETAINER		NW	5
RW41000226-102	SPOOL & SLEEVE	RW383	OHC	1
RW41000248-101	SPOOL & SLEEVE	1-259	NW	1
RW41000413-101	SPOOL & SLEEVE	286	NW	1
RW41000005	PISTON	04-001 to 04 -004	RWK	4
RW41000424	TRUNNION		NS	1
RW41000485-102	SPOOL & SLEEVE	038 / 037	NS	2
RW41000584-101	SPOOL & SLEEVE	265	OHC	1
RW41001682-101	SPOOL & SLEEVE	1-250,2-346	OHC	2
S11052-18Q	PISTON RING SET		NW	2
S11065-10-5	SEAL		NW	14
S11065-3T	SEAL		NW	3
S11065-5-5	SCRAPPER		NW	13
S11065-9T	RING		NW	23
S12562-0121	SEAL		NW	10
S12562-120	SEAL		NW	69
S12562-210	SEAL		NW	15
S12563-011	SEAL		NW	7
S12604-112	PLUS SEAL(R) ASSY		NW	6
S12735-3005	SEAL		NW	7
S12766-117	RING		NW	100
S13077-114	SEAL		NW	18
S1565-61419-18	DECAL		NW	8
S2701-001	RELAY BASE		NW	1
S2701-002	RELAY BASE		NW	1
S2805-011	FILAMENT INSTRUMENT PANEL		NW	30
S2805-076	FILAMENT		NW	9
S2805-077	FILAMENT LP FUEL SWITCH		INSP	10
ML-307	FILAMENT WING TIP		INSP	10
S2805-508 / GEQ50T4CL	LAMP NAV		NS	10
S30361-0214	SEAL RING		NW	9
S30392	SEAL		NW	14
S30772-114-G1N	SEAL		NW	2
S30775-3001	SEAL		NW	3
S32216	SEAL,ROTARY		NW	70
540-011-119-21	NUT PLAIN		NW	5
S6140-65612-003	CABLE		NW	4
S6120-60901-005	CABLE ASSY		NS	6
S6120-62579-18	HINGE		-	1

S6120-65165-19	HINGE		-	4
S6120-66132	TCB SUPPORT		NS	1
S6126-50101	DOOR KIT		NS	3
S6150-60106-003	TUBE ASSY		NS	1
S6155-62053-3	RELAY BOX COVER		NS	1
S6155-62053-4	RELAY BOX COVER		NS	1
S6164-60330-042	CABLE ASSY		NW	1
A-703CSM	CONTACTOR STARTER		RP	1
SD113G	CONTACTOR STARTER		INSP	1
SGT233-2	SPACER		NS	10
SGT526-1	SPOOL & SLEEVE		NW	11
SGT528-1	WINDOW		NW	1
SGT531-1	ORIFICE		NW	2
SGT533-1	WASHER		NW	50
SGT539-1	DECAL		NW	13
SL50029-102 / ABC7192	BOLT		NW	2
SL5101E0017A	LABEL		NW	1
SL5101E0011A / DHS1761B	LABEL		NW	20
SL5114-20-7	BONDING LEAD		NW	2
SL5114-21-5	BONDING LEAD		NW	2
SL5114-21-6	BONDING LEAD		NW	2
SL5181-04-4	BOLT SPECIAL ENG. DOOR		NW	4
SM150D2 / HC007H0798	BATTERY CONTACTOR		INSP	1
SM601BA40A14 / HC007H1297-002	RCCB		INSP	1
SP-135PLUS	WELDING AND CUTTING EQUIPMENT		NW	1
SP157-48-12	RIVET		NW	2
SP-4	PLUG		NW	4
SP-5	PLUG		NW	4
SP-6	PLUG		NW	5
SR10604A	CONNECTOR		NW	6
SSL 3116	VALVE		NW	20
SSL118	VALVE		NW	20
SSL5132	VALVE		NW	20
ST107Q	PRESS TRANSMITTER		OHC	1
ST506A	PRESS TRANSMITTER		OHC	1
STD3017E8	PACKING		NW	15
STMD16	SOCKET		NW	1
T101303	SOCKET		NW	1
T204-076-202-100B	SPANNER WRENCH		NW	1
T41000470-20-002	SEAL INSTALLATION TOOL		NW	1
T41001290-5	PLUNGER REMOVA		NW	2
T41105950-6	ALIGHMENT TOOL		NW	1
TF936-7218N-582	SEAL		NW	110
TF712-014N	SEAL PISTON		NW	66
TF712-701N	SEAL		NW	42
TMU101A	FLEXOCKET		NW	1
TNC-RPL6M55	CONNECTOR, RADIO FREQ		NW	2

X00079-401	AUDIO UNIT	64	OHC	1
XW20345-360-50	CONVERTER	3917-A	OHC	1
2588302-3	GYRO DIRECTIONAL	5100248	OHC	1
HDD4SF2H06	RELAY ( 1000 OHM )		-	37
RU50128	WASHER KEY		-	7
CEC4-3299-01 (CEC3299-01)	PACKING & RETAINER		NW	5
LN9345-16	NUT		NW	48
LN9025-0510K	LOCK WASHER		NW	20
LN9082-08X44S	BOLT		NW	50
LN9161-05M	NUT		NW	4
C42641-100	S/S ASSY		NS	1
DU2310A	SEAL		NW	5
PT6T-3	ENGINES CONSIST OF 2 POWER SECTION PN. 3017600 & GEARBOX PN. 3024780		REP.	2
3024780	GEARBOX ASSEMBLY	CP-GB-2141 / CP-GB-1636	REP	2
3017600	POWER SECTION ASSEMBLY	CP-PS-61254, 61982, 61983, 73001	REP	4
-	WORK AID FOR TAIL BOOM ATTACHMENT	-	NS	1
<b>BAE 146 SERVICEABLE PARTS</b>				
WL604AMA22	AIRSPPEED INDICATOR	AH626	INSP	1
XW20343-1250B4 / 02314M-10-4	ARM ASSY		NW	11
XW21872-11/XW21132-11	WIPER MOTOR	D388	INSP	1
9-328-19	FUEL FLOW INDICATOR	1931 (TAG DD. 12/11/14)	REP	1
9-328-19	FUEL FLOW INDICATOR	56 (TAG DD. 12/11/14)	REP	1
9-328-19	FUEL FLOW INDICATOR	3305 (TAG DD. 12/11/14)	REP	1
9-328-19	FUEL FLOW INDICATOR	1656 (TAG DD. 12/11/14)	REP	1
516CUF1	NAV SELECTOR	139 (TAG DD. 18/11/14)	REP	1
516CUF1	NAV SELECTOR	119 (TAG DD. 20/11/14)	REP	1
501-1-13775-008	DC STARTER MOTOR	TE1541	OHC	1
509-1-02530-001	TRANSFORMER RECTIFIER	RG0309 (Tag dd. 11/3/08)	INSP	1
509-1-02530-001	TRANSFORMER RECTIFIER (TRU)	TE1173	SVC	1
522-2457-020	CONTROL RADIO	23007 (TAG DD. 5/11/14)	REP	1
522-2996-011	RECEIVER MB	16700 (TAG DD. 14/11/14)	REP	1
522-4798-001	ALT CONTROL	2331	OHC	1
622-1181-002	TRX VHF COMM	13092 (TAG DD. 5/11/14)	INSP	1
622-1396-101	TRX VHF COMM	10852 (TAG DD. 18/11/14)	REP	1
622-2921-002	TRANSCEIVER DME	10822 (TAG DD. 13/11/14)	RP	1
622-4160-015	ALTITUDE INDICATOR	4485 (TAG DD. 4/11/14)	INSP	1
1U457-001	ADF CONTROL	T196 (TAG DD. 13/11/14)	REP	1
1U471-001	ADF CONTROL	T234 (TAG DD. 11/11/14)	REP	1
1U457-001	ADF CONTROL	T251 (TAG DD. 13/11/14)	REP	1
A-703CSM	RELAY	CH-50319 (TAG DD. 19/12/14)	REP	1
A-703CSM	RELAY	CE-61519 (TAG DD. 19/12/14)	REP	1
7002353-913	AIR DATA SENSOR	05092226 & 05082224	NE	2
7002353-913	DATA SENSOR ASSY	05102227 & 05102232	NW	2
7934111-16SA	CLAMP		NW	9

MI-585161-2	WX RDR REC TX	3365	REP	1
2588317-925	INSTRUMENT COMPARATOR	88103453	OHC	1
WL1107AM-MS4	SERVO ALTIMETER	AG251	RP	1
3502B000	FLOW CONTROL AND SHUT OFF VALVE	B323558-10	SV	1
3503B000	RECIRCULATION VALVE	509535-2	INSP	1
HC535H0187-000	RING ASSY		NW	2
HC537H0477-002	SEAL		NS	2
HC130J0001-000	COLLAR AIR BRAKE SAFETY		SV	1
HC132H0006	JACKING PAD		SV	1
HC921H0451-010	CONTROL SYSTEM	SBYDH/92/544	TST	1
HC923B0181-002	WELDED CAN ASSY		NW	2
HC921H1220-000	PANEL CB	22281	-	1
HC923H1327-000	LINK	145266	NW	2
HC923H1328-000	SPARK CAP		NW	2
SA7670006-123	PIPE		NW	1
SA7670006-137	HOSE BRAKE		INSP	1
SA7670006-138	HOSE BRAKE		INSP	1
SA7670006-545	HOSE		NW	1
0101KPU-2	PROCESS UNIT	971058	AR	1
10113	AIR SPEED SWITCH	111	AR	1
10125	ALTITUDE SWITCH	111	AR	1
10125	ALTITUDE SWITCH	499	AR	1
10164	AIR SPEED SWITCH	366	AR	1
10181	AIR SPEED SWITCH	236	AR	1
4204001	P T U	BC69	AR	1
4501882	APU POWER CONTROL (MODEL T-62T-46C3)	V7610055	AR	1
56775H1 ISS4	SERVO VALVE	FYH125773	AR	1
345619604	ELT REMOTE SWITCH	REV B	AR	1
104628003	MLG JACK	DH011095, DRG325-90	AR	2
676-301-226 / 11RS214/1	SYNCHRO RESOLVER	889070	AR	1
676801007	FLAPS CONTROL	VEL/DRG/1331/90	AR	1
676301009	GEAR BOX SPOILER	DRG/1385/83	AR	1
676101005	FLAP CONTROL UNIT	DRG1102/90	AR	1
676301211	SYNCHRO RESOLVER	1182C1170	AR	1
676301211	SYNCHRO RESOLVER	12850522	AR	1
676501001	GEAR BOX	DRG/1561/82	AR	1
0101KPU/2	PROCESSOR UNIT	XD5365	AR	1
0102KPU/2	PROCESSOR UNIT	XD5884, XD5887	AR	2
0201 KTU/33	FUEL TANK UNIT	TU107008	AR	1
0201 KTU/35	FUEL TANK UNIT	TU106541	AR	1
0733040	WATER DRAIN VALVE		AR	1
102LAA2	YAW DAMPER ACTUATOR	1767, 1222	AR	2
110RAA2	SERVO ACTUATOR	2643	AR	1
108-AA4-511	FAN BLOWER	462475, 468092	AR	2
108AA4511	AIR SCREW	449687S	AR	1
102LAA-2	YAW DAMPER ACTUATOR	1333	AR	1
114-158	SPOILER INDICATOR	86070071	AR	1

114-158	SPOILER INDICATOR	96080664	AR	1
114-158	SPOILER INDICATOR	84100083	AR	1
114-158	SPOILER INDICATOR	99070734	AR	1
124-152-3	TEMP PRESS INDICATOR	86050136 , 85020122 , 83120095 , 83110087	AR	4
124-152-3	TEMP PRESS INDICATOR	83110088 , 83040021 , 81E0007	AR	3
124-181-1	IND BRAKE PRESSURE	82010009 , 87090278 , 89070397	AR	3
124-183	OUTSIDE AIR TEMP IND	85060085	AR	1
124-183	OUTSIDE AIR TEMP IND	89120220	AR	1
131-12-00	PANEL CB	-	AR	1
131-11-00	PANEL CB	-	AR	1
1912-02 (AD-969-DW)	ANTENNA LIGHTNING ARRESTER	1479	AR	1
15900-906	CABIN ALT RATE INDICATOR	2466	AR	1
15900-906	CABIN ALT RATE INDICATOR	2458	AR	1
172938-001	S S U	10515 , 10536 , 10500	AR	3
172938-001	S S U	10786	AR	1
1978-300-1	VALVE SPLITER	20437401240	AR	1
1U459-001	HF COM SELECTOR	T181	AR	1
1RF130	TRANSISTOR	UNK	AR	1
1U471-001	AUDIO CONTROL PANEL	T671	AR	1
1U471-001	AUDIO CONTROL PANEL	T541	AR	1
203SUM1	HEAT SENSOR	AE179 , AD921	AR	2
2-043-001-R32	COMPRESSOR BLADE	-	AR	40
2-043-001-R34	COMPRESSOR BLADE	-	AR	35
2-043-009-08	SPINNER & CAP		AR	1
2-043-009-10	SPINNER & CAP		AR	1
2N3740	TRANSISTOR	UNK	AR	1
2LA002606-06	LANDING GEAR LIGHT		AR	1
2N3767	TRANSISTOR	UNK	AR	1
21B107-6-A / 57241-4	MOTOR GENERATOR CONTROL	35	AR	1
2353-1	AIRCRAFT BATTERY	E02884	AR	1
2313M-158-1	MOTOR CONVERTER	00024	AR	1
2313M-158-2	MOTOR WIPER	826	AR	1
2587335-114	VERTICAL GYRO	90097333	AR	1
2591200-901	MAGNETIC COMPENSIATOR	81074151	AR	1
2591200-901	MAGNETIC COMPENSIATOR	810741050	AR	1
2591201-903	COMPASS COUPLER	87047205	AR	1
2591201-903	COMPASS COUPLER	81104723	AR	1
2651011	FWD(R/H) ENGINE MOUNT	1151	AR	1
304ADA/1	TRANSDUCER	AC246	AR	1
350280000-003	FLOW CONTROL VALVE	A4176609-2	AR	1
35008-13	CFD CONTROL UNIT	B1348	AR	1
3551H1	MICROFILTER	FYH120402	AR	1
3551H1	FILTER	FYH173522	AR	1
3545H5	SERVO	FYH142288	AR	1
3545H6	SERVO	FYH123462	AR	1
3545H7	SERVO UNIT ASSY	FYH162861	AR	1
37070-235	SAT/TAS/TAT COMP	208 , 657	AR	2



3807H2	AIR BRAKE ACTUATOR	FYH172877	AR	1
3807H2	AIR BRAKE ACTUATOR	FYH166407	AR	1
392614-1-1	REGULATOR PRESSURE	P-2903	AR	1
4-013-03	DIMMER INCANDESCENT	1186	AR	1
4-013-03	DIMMER INCANDESCENT	1170	AR	1
4-013-03	DIMMER INCANDESCENT	1180	AR	1
4-013-03	DIMMER INCANDESCENT	1174	AR	1
4019700-902	A D I	82050340	AR	1
4019700-902	A D I ( ALTITUDE DIRECTOR INDICATOR )	82010293	AR	1
401RGU-FA2	RATE GYRO UNIT	AE590	AR	1
401RGU-FA2	RATE GYRO UNIT	AE580,AE290	AR	2
4034559-901	DISTANCE BEARING	86111669	AR	1
4037539-906	H S I	84090298 , 83070002	AR	2
407/1/32460/000	CURRENT TRANSFORMER	TH675, TG699, TG700,TH658,TH653,TH667	AR	6
4101H2	HYDRAULIC	FYH154978, FYH146569	AR	2
4100670-005	HYD FLIGHT CONTROL SERVO ACTUATOR	1466	AR	1
452-0133	ELT 406 ( 452-0133 )	170-07344	AR	1
4554-514-C	PC BOARD	1114	AR	1
46546-509-0	PC BOARD	1205	AR	1
46546-510-0	FUEL TRANSFER	1004	AR	1
46546-512-0	PC BOARD	1063	AR	1
46546-513-0	PC BOARD	1012	AR	1
46546-513-0	PC BOARD	1011	AR	1
46546-513-0	PC BOARD	1020	AR	1
46546-513-0	PC BOARD	1582	AR	1
46546-514-0	PC BOARD	1007	AR	1
46546-514-0	PC BOARD	2251	AR	1
46546-514-0	PC BOARD	2092	AR	1
46546-514-0	PC BOARD	3419	AR	1
46546-515-0	PC BOARD	1024	AR	1
46546-515-0	PC BOARD	1067	AR	1
46546-515-0	PC BOARD	1070	AR	1
46546-515-0	PC BOARD	1025	AR	1
46546-515-0	PC BOARD	1028	AR	1
46546-515-0	PC BOARD	1029	AR	1
46546-515-0	PC BOARD	1032	AR	1
46546-515-0	PC BOARD	1030	AR	1
46546-524	CIRCUIT BOARD	1254	AR	1
46546-524-0	PC BOARD	1113	AR	1
473597-4-07	SMOKE DETECTOR	9393 , 9392 , 9395 , 10364	AR	4
473996-1	FIRE EXTINGUISHER	63601EL	AR	1
473997-1	FIRE EXTINGUISHER	61281EL	AR	1
4835-101-0	DOWTY ELEC	1172	AR	1
48351-301-0	M W S ASSEMBLY	11	AR	1
50697	HYD FILTER		AR	1
50889	HYD FILTER		AR	1
515CUF3	ALTITUDE SELECTOR	433	AR	1

522247	IND ENGINE VIBRATION	2881272	AR	1
5234-02	PC BOARD	383	AR	1
52802-302	LIGHT WORKING		AR	1
522-3616-201	DME CONTROL	1838	AR	1
60-2388-101	PACK ELECTRONICS DRIVE STROBE	1175	AR	1
6001-1-1	DISPLAY SWITCH UNIT	630	AR	1
622-1396-101	TRANSCIEVER, VHF	10508	AR	1
622-2921-002	DISTANCE MEASURE EQUIPMENT	13722 ,12004	AR	2
622-3255-001	NAV RECEIVER	8393	AR	1
622-3856-001	ADAPTER RECIEVER	923	AR	1
622-4160-015	RADIO ALT INDICATOR	4484 , 3823	AR	2
622-7878-201	ATC TRANSPONDER	11006	AR	1
622-7878-201	ATC TRANSPONDER	11010	AR	1
622-8971-022	TCAS	1442	AR	1
622-9353-223	TCAS	3689	AR	1
6836	BRUSH STARTER	46	AR	1
622-9353-211	TCAS	31	AR	1
23491	AIRCRAFT BATTERY	N2340	AR	1
72189	SERVO VALVE ASSY	84	AR	1
72-130003-001	SMOKE DETECTOR	7393	AR	1
2-183-220-05	FUEL FILTER	856	AR	1
741SUE3	YAW COMPUTER	8040 , 1174 , C1163	AR	3
741SUE3	YAW COMPUTER	1305	AR	1
750103-1	PRESSURE SWITCH	321	AR	1
773900-17	FCU (Repair)	F15521	AR	1
88000-4102	CLOCK ACFT	0816883 , 0816911	AR	2
9-127-48	TRANSMITTER FUEL	6228	AR	1
91652-0	RELIEF VALVE	K0029	AR	1
91666-0	HYDRAULIC VALVE	LK0011, LK0018	AR	2
91666-0	HYD ACCUMULATOR	LK002	AR	1
91666-0	HYD ACCUMULATOR	LK0300726	AR	1
93A151-20	CONTROL UNIT	25746	AR	1
965-0412-002	AIR DATA COM	581 , 996	AR	2
965-0476-088	GPWS	2863	AR	1
9750E0640	RED BOX BATTERY	RK3885,L2347,L5350	AR	3
A60-24051-2	BRAKE PRESS TRANSMITTER	L1234 , L1240	RP	2
A-33-8300-04	CHASSIS ASSY	272 , 157	AR	2
A-703CSM	CONTACTOR RELAY	CJ-40475,CH46420	AR	2
A-703CSM	CONTACTOR RELAY	CJ-86774 , CJ-27646	AR	2
A-957CSD	CONTRACTOR RELAY	CK20998, CE57667, CK36810,CH40350	AR	4
AE20556	ANTI SKID	GY151	AR	1
ATEST00334-002	CARGO BAY SMOKE	ULT-0007-03	AR	1
ATEST00335-000	CARGO SMOKE	ULT-0005-04	AR	1
AL66816	SOLENOID	612519 DA19	AR	1
B00A214269A	TEMP CONTROL VALVE	UNK	AR	2
B03A214267A	DISCHARGE VALVE	DGH870777	AR	1
C81506-2	S S U	133 , 132 , 120 , 117	AR	4

C81606-2	S S U		994,998	AR	2
C81606-5	S S U		614 , 208	AR	2
DMO18.3	ANTENNA ELT		4568, 5957	AR	2
D206329	DYNAMIC MICROPHONE		60837008	AR	1
D11842 ISS 3	TRANSDUCER		709314	AR	1
D11852 ISS 3	TRANSDUCER		109524	AR	1
D11986	TRANSDUCER		113877	AR	1
D11986	TRANSDUCER		113876	AR	1
D45297	POTENSION MET		05K00643	AR	1
D758	CSD BLEED TOOL		-	-	1
D7670A	CSD DRAIN ADAPTOR		-	-	1
D84004	BRAKE FAN COVER & AIR SCREW		AD2071, AC2U1, ACT41	AR	3
DGR2351A000	ANTI ICING VALVE		A876530-21	AR	1
DRG2766A000	ALTITUDE LIMITER		386543-12	AR	1
DRG2766A000	ALTITUDE LIMITER		875708-1	AR	1
DRG2764A000	DISCHARGE VALVE		A762352-1	AR	1
DRG2764A000	DISCHARGE VALVE		507019-4	AR	1
DRG2767A000	PRESSURE OXYGEN INDICATOR		315857-4	AR	1
DRG3536B000	FRESH AIR VALVE		524860-3 , 07-2157-5	AR	2
DRG4679000	TEMPERATURE CONTROL		409074-1	AR	1
DRG4325C000	TEMP CONTROL IND		B1787643,123523-2	AR	2
DRG4685C000	WATER EXTRACTOR		2061	AR	1
E327AD	POWER MONITOR ELEC		CK35837	AR	1
E37043D	CURRENT MONITOR		044E	AR	1
GE387	BULB			AR	25
GE4559	BULB			AR	1
GE4594	BULB		NA	AR	5
GE5557	BULB		NA	AR	2
GE6180	BULB			AR	21
H301BDM1	HORIZON GYRO		6658	AR	1
HC1H0005-1998	ELECTRIC ASSY		DHB 7	AR	1
HC210000-30-0	AIRCON DUCT			AR	1
HC210J0038-000	AIRCON DUCT		R3/D30	AR	1
HC276H0152-000S	MULTI VALVE		RW32780-4	AR	1
HC276H0152-001S	MULTI VALVE		RW32780-4	AR	1
HC276H0203-003	GEAR BOX LEVER		15182	AR	1
HC281-H0020-000	PIPE ASSY			AR	1
HC281-H0052-000	PIPE ASSY			AR	2
HC281-H0065-000	PIPE ASSY			AR	1
HC281-L0010-010	PIPE ASSY			AR	1
HC282H0031-000	BRAKE MOUNTING			AR	1
HC282-H0103-000	FUEL VALVE		-	AR	2
HC282-L0091-000	PIPE ASSY			AR	1
HC282-L0092-020	PIPE ASSY			AR	1
HC2820H0316-000	MOUNTING VALVE		E15	AR	1
HC290-B0015-000	VALVE			AR	1
HC291B0011-000	TANK HYDRAULIC GREEN SYSTEM		F26	AR	1

HC291B0011-000	TANK HYDRAULIC YELLOW SYSTEM	B/D/209A	AR	1
HC282-H0112-000	PIPE ASSY		AR	2
HC282-H0113-000	PIPE ASSY		AR	2
HC282-H0116-200	PIPE ASSY		AR	1
HC282-H0117-001	PIPE ASSY		AR	1
HC282-H0123-003	PIPE ASSY		AR	1
HC282-H0138-000	PIPE ASSY		AR	1
HC282-H0324-000	BRACKET		AR	1
HC282-H0325-000	PIPE ASSY		AR	2
HC282-H0330-000	PIPE ASSY		AR	1
HC282-H0347-001	BRACKET		AR	1
HC282-L0029-000	CAP		AR	1
HC282-L0029-002	CAP		AR	1
HC282-L0032-002	PIPE ASSY		AR	1
HC282-L0032-003	PIPE ASSY		AR	1
HC282-L0034-000	PIPE ASSY		AR	1
HC282-L0090-000	PIPE ASSY		AR	1
HC282-L0091-010-01	PIPE ASSY		AR	1
HC282-L0092-028	PIPE ASSY		AR	1
HC282-L0092-036	PIPE ASSY		AR	2
HC282-L0092-054	PIPE ASSY		AR	1
HC282-L0092-064	PIPE ASSY		AR	1
HC282-L0095-004	PIPE ASSY		AR	2
HC282-L0095-010	PIPE ASSY		AR	1
HC282-L0091-006-01	PIPE ASSY	-	AR	3
HC391-1003-000	AIRCON GROUNDTEST LIGHT	DHB 12	AR	1
HC391H0007-000	ENGINE PANEL	DHB 9	AR	1
HC391H0098-000	PANEL LIGHT COCKPIT	DH010	AR	1
HC391H00100-000	AIRSUPPLY PANEL	DHB 4	AR	1
HC391H004C	FUEL PANEL	DHB 5	AR	1
HC391H0098-002	LIGHT COCK PIT PANEL	DH008	AR	1
HC391H0113-000	HANDSET PANEL	DH 013	AR	1
HC391H027-004	HDY CONTROL PANEL	DN 535	AR	1
HC391H0188	APU INDICATOR	DHB2	AR	1
HC39SH5024-155-2	COMPASS PANEL	NP 0505	AR	1
HC396H0544/005	PC BOARD	167	AR	1
HC52880033-00	SLEEVE		AR	2
HC535-B0194-000	PANEL TANK BRACKET		AR	1
HC921H0353-000	PANEL LAMP	DH008	AR	1
HC921H0467-000	CIRCUIT ASSY	43	AR	1
HC921H0467-000	CIRCUIT ASSY	46	AR	1
HC921H0467-000	CIRCUIT ASSY	50	AR	1
HC921H0478-000	PC BOARD	SBY/DH/90,471	AR	1
HC921H0448-000	PC BOARD	013	AR	1
HC921H0450	PC BOARD	021	AR	1
HC921H0450-000	PC BOARD	101	AR	1
HC921H0451-000	PC BOARD	GP1466/5	AR	1

HC921H0451/004	PC BOARD	SBY082	AR	1
HC921H0472/002	STALL IDENT COMPARATOR	409 SBY/OH/88	AR	1
HC921H0473/000	Q FEEL HEATER FAIL	SBY/DH/86:1037	AR	1
HC921H0473/000	PC BOARD	527	AR	1
HC921H0506/000	PC BOARD	8	AR	1
HC921H0513/000	PC BOARD	088	AR	1
HC921H0520/000	PC BOARD	SBY/DH/85.094	AR	1
HC921H1637	RESISTOR BOX	GE040	AR	1
HC921H1220/000	CB PANEL	50181	AR	1
HC921-H0083-000	PANEL CB	61782	AR	1
HC921-H5777/200	ENGINE STARTER DC POWER	BR0015595	AR	1
HC921H0514	PC BOARD	26	AR	1
HDS8SF2L03 / 32270	COIL RELAY	HEE812631621, HEE812631596	AR	2
H2010H6044-00	SPRING		AR	1
KCA0105W	STANDBY COMPASS	K5294	AR	1
KCA-0105W	STANDBY COMPASS	SAV21338	AR	1
MS14154-7 1/2	CB CABIN FAN		AR	1
MI-585162-2	RADAR ANTENNA	3130	AR	1
MI-585164	RADAR ANTENNA	2083	AR	1
MPEV3-011-13-681	DC PUMP	F9817774	AR	1
MPEV3032EA1	AC PUMP	F9136068	AR	1
MPEV3032GBI	AC PUMP	F3817846	AR	1
ND0075-1764	ELECTRSTATIC FILTER	L142292 , L142294	AR	2
PC-250	STATIC INVERTER	4107	AR	1
PC-250/200102-1	STATIC INVERTER	5520	AR	1
PV1591C	CONTROL UNIT	FA8485	AR	1
P458A0125-02	ELECTRO SERVO VALVE	80	AR	1
HC921H0409-000	FUSE PANEL	2-14-83	AR	1
SBY/DH/90	PC BOARD	473,471	AR	2
SM600BA	GB REMOTE CONTROL	8,342,940	AR	2
SM601BA	GB REMOTE CONTROL	4020, 4087	AR	2
SM601BA	GB REMOTE CONTROL	01055, '04106, '01741	AR	3
WKA473925	CARGO ELECTRONIC UNIT	6373 , 6374	AR	2
WL-0201KID2	FUEL INDICATOR	TT3300	AR	1
WL-0201KID1	FUEL INDICATOR	TT638,TT764,TT5558	AR	3
WL106AMA7	MACH AIR SPEED	AH361,AG1707,AH441	AR	3
WL651RSA5	N2 RPM INDICATOR	C-AC780 , AG355 , AJ800 , CAH438	AR	4
WL651RSA6	N2 RMP INDICATOR	CAD203	AR	1
WL706RSA4	TURBINE GAS TEMP IND	AD411 , AD274 , AD276 , AD283	AR	4
WL719RSA1	N1 RPM INDICATOR	AH204 , AC670	AR	2
WL719RSA1	N1 RPM INDICATOR	AF345	AR	1
WL719RSA1	N1 RPM INDICATOR	AK424	AR	1
WL719RSA5	N1 RPM INDICATOR	AF491	AR	1
WL719RSA1	N1 RPM INDICATOR	AH391	AR	1
WL719RSA1	N1 RPM INDICATOR	AJ458	AR	1
WL719RSA1	N1 RPM INDICATOR	AC232	AR	1
PKD22-7-81	SEAL		AR	1

T411-AE-1001-C	ELECTRONIC TIME DELAY		AR	1
T412-AJ-1501-C	RELAY		AR	1
T400-ALJ-1001-JC	RELAY		AR	4
T400-ALJ-2402	RELAY		AR	1
537	APU BRUSH	NA	AR	14
AC67726	HYDRAULIC FUSE	DV491 , DV492	AR	2
AC67728	RELIEF VALVE	J8151A	AR	1
9082	HI TEMP INDICATOR	68048158/4	AR	1
65960	SOLENOID VALVE	EL153	AR	1
473270	SPEED PICK UP N/L	273	AR	1
CN4950899	ANTI SURGE VALVE	1695	AR	1
0101KPR1	FUEL CONTENT	XD8909 , XD6259	AR	2
0101KPU-2	PROCESSOR UNIT	XD6440 , XD9141	AR	2
0101KPU-2	PROCESSOR UNIT	XD5885 , XD5886	AR	2
0101KPU-2	PROCESSOR UNIT	XD7121 , XD10725,XD7794	AR	3
010-0801-0010	ROD ASSY	6	AR	1
012-0074	FUSE 2 AMP	NA	AR	6
10-205-1	ANTENA	274	AR	1
10-397650-1K	EXCITER IGNITION	9103R001	AR	1
10-397650-1K	EXCITER IGNITION	93491941	AR	1
100-045-512	BRAKE FAN MOTOR	531631	AR	1
10224-1	PRESSURE TRANSDUCER	254 ,184 , 181	AR	3
102-000	TEMP SWITCH	120260	AR	1
12315-2	PRESSURE SWITCH	234	AR	1
124-152-3	TEMP PRESSURE INDICATOR	85020122 , 86050130,83120095,83110087,83040021	AR	5
124-593-2	FLAP POSITION INDICATOR	87040155 , 89120333	AR	2
124T1341	E.G.T INDICATOR	81100005	AR	1
12525-15	FOKKER F-28	AAC131	AR	1
12529-1	PRESSURE SWITCH	0030	AR	1
14539-1	CABLE TYPE PFGL-10	NS31/U	AR	1
14660	ANTENNA ARRESTER	6941	AR	1
15258-1	PRESSURE SWITCH	2483TW	AR	1
15258-1	PRESSURE SWITCH	2457	AR	1
17-20N	ANTENNA ARRESTER	7207	AR	1
1778686-655	GYRO COMPASS	1040972	AR	1
1-899-1510-61226-15	TGT AIR BRAKE SENSOR	127555	AR	1
200877664	SHAFT M/G	-	AR	2
200898005	UPLOCK UNIT	WEY DRG373/81	AR	1
200898006	UPLOCK UNIT	CWDD/DRG45/89	AR	1
200885002-5	UPLOCK UNIT	WEY-DRG-110-5C	AR	1
2335-139	SWITCH PRESSURE	N539	AR	1
20216-213-01	SCREEN SEAL	UNK	AR	1
2117576-3	CONTROL DISPLAY UNIT	68-328	AR	1
2117608-1	TRANSDUCER PRESSURE	91-117, 51-200	AR	2
21M27-13	PRESS SWITCH	M169, K113	AR	2
21M27-23	PRESS SWITCH	F035915	AR	1
21M27-4	PRESS SWITCH	M253	AR	1

21M27-4	PRESS SWITCH	P104A	AR	1
2-303-431-02	FILTER	-	AR	1
2-303-491-02 (91547-SOCN )	DUAL HEAT EXCHANGER	124094	AR	1
2-303-491-02 (91547-SOCN )	DUAL HEAT EXCHANGER	424094	AR	1
2-303-626-01	N2 PICKUP SENSOR	991402600377	AR	1
2-303-742-03	IGNITER LEAD		AR	2
2-303-763-02	EXCITER CABLE	1	AR	1
2-303-769-03	IGNITER LEAD	7697110049	AR	1
2587335-114	VERTICAL GYRO	89096956	AR	1
2587335-114	VERTICAL GYRO	86105863	AR	1
2594860-901	DIRECTIONAL GYRO	80050508	AR	1
2594860-901	DIRECTIONAL GYRO	90041078 , 90071102	AR	2
270-526-8201-002	BULB		AR	2
270-526-8201-006	BULB		AR	2
2-023-035-09	SUN GEAR		AR	1
2-083-250-29	GEARBOX MODULE ROD	83J002	AR	1
301ADA/FA/1/ 10-61982-11	ACCELERATER METER	AG654	AR	1
301ADA/FA/1	ACC METER DETECTOR UNIT	AG168	AR	1
30-231-15	SMOKE DETECTOR	29347	AR	1
30-1401-1	ANTI COLLISION LIGHT	2606	AR	1
304-ADA-1	ACCELEROMETER	A6444, AP178	AR	2
3101-08	FIRE SENSING	4825	AR	1
3101-08	FIRE SENSING	7941	AR	1
329005	DOWTY ROTOR VALVE	833, 2264	AR	2
3502B000	FLOW CONTROL SHUT OFF	RA233305-5	AR	1
3502B000-003	FLOW CONTROL SHUT OFF	A417609-2	AR	1
3502B000-003	FLOW CONTROL	923544-1	AR	1
3549H1	MICROFILTER	FYH125604,FYH118837	AR	2
3567HI	FAIREY MICRO FILTER	FYH118825 , FYH124942	AR	2
3888302-3	LEAD IGNITER PLUG	NA	AR	1
4-013-01	DIMMER	852	AR	1
4037539-906	H.S.I	85110343	AR	1
4325C000	NORMAL AIR GARET	421197/2	AR	1
4325C000	NORMAL AIR GARET	421197/5	AR	1
448D300-1	ATTENDANT HAND SET	1431	AR	1
448D1001-1	HAND SET	9013	AR	1
448D1001-1	HAND SET	2011	AR	1
448000-1	HANDSET	1417	AR	1
4501700A	POWER SYSTEM	106	AR	1
4502KGB-1	RPM PULSE PROBE	XP3430MOD	AR	1
4502KGB-1	RPM PULSE PROBE	XP233	AR	1
4951090	BLEED AIR VALVE	0244C	AR	1
509/1/02530/001	T R U	TE0781,TE0874, TE0605, TE0723	AR	4
522-2996-011	MARCER BEACON	13999 , 18064	AR	2
522-3443-000	ANTENNA COUPLER	6786	AR	1
522-4209-002	DIST.MEASURING EQUIPMENT	1634	AR	1
53183-109	SWITCH LOW TEMPERATURE	J0291,J0097,R1482	AR	3

53183-110	TEMP SENSOR	HS15	AR	1
53183-111	OVERHEAT DETECTOR SWITCH	A729, A214	AR	2
535363A2	KIT		AR	2
53183-107-03	SWITCH LOW TEMPERATURE	A4055	AR	1
53183-107-03	SWITCH LOW TEMPERATURE	A4635	AR	1
55820SOCN / C5908597	SERNO	KC95-158, MFR 25414	AR	1
568-1-25663-001	HYD FUEL PUMP	822	AR	1
568-1-25663-001	HYD FUEL PUMP	841	AR	1
568-1129665-001	FUEL BOOSTER PUMP	7902	AR	1
569-1-5665-001	FUEL BOOSTER PUMP	1173	AR	1
568-1-5665-001	FUEL BOOSTER PUMP	965, 1012, 806	AR	3
568-1-25665-001	FUEL BOOSTER PUMP	156, 173, 260	AR	3
568-2129971-000	VALVE	-	AR	1
59501-9048900-2	EXCITER IGNITION	5131112	AR	1
59501-9048900-2D	EXCITER IGNITION	UNK	AR	1
622-2224-001	ATC TRANSPONDER	8188	AR	1
622-2224-001	ATC TRANSPONDER	2681	AR	1
622-2615-311	FLIGHT PROFIL COM	2519	AR	1
622-2615-311	FLIGHT PROFIL COM	1307	AR	1
622-3699-001	ADF RECEIVER	1609	AR	1
622-3371-001	HF RECEIVER	4683 , 3823	AR	2
622-4096-002	PASSENGER ADDRESS	5520	AR	1
622-9353-211	TCAS INDICATOR VERTICAL	167	AR	1
6435-001	U/C SELECTOR SWITCH	44-91	AR	1
658SUE5	MONITOR COMPUTER	1164	AR	1
6610M43	VIBRATION SIGNAL UNIT	69090 , 128640	AR	2
676701211	MOUNTING ROD	DRG204681, DRG310385,UNK,DRG310485	AR	4
6711-022-00	LAMP	104-90	AR	1
6711-022-00	INCANDESCENT DIMMER	240-85-86	AR	1
70-AA6-571	COOLING FAN	U90556	AR	1
70210-2022550-5-3	TNS ACTUATOR	61-156 , AS8944 , 76-615	AR	3
70210-2022550-5-3	TNS ACTUATOR	34254	AR	1
70210-544654-6	ACTUATOR ROTARY	4949	AR	1
70-AA6-521	AIRSCREW	480254	AR	1
716951	DC PUMP	F8931923	AR	1
741SUE3	YAW COMPUTER	1174 , C1163 , 8040	AR	3
777-1492-001	A D F RECEIVER	1249	AR	1
777-1492-001	A D F RECEIVER	803	AR	1
7913003/K	REFUELLING VALVE	351/F	AR	1
8-060-02	PC BOARD	70316	AR	1
8-060-02	PC BOARD	7386	AR	1
8-060-02	PC BOARD	79337	AR	1
8-060-02	PC BOARD	79101	AR	1
8-060-02	PC BOARD	79080	AR	1
8-060-02	PC BOARD	79063	AR	1
8-060-02	PC BOARD	73887	AR	1
8-060-02	PC BOARD	73891	AR	1



8-060-02	PC BOARD	171347	AR	1
8-060-02	PC BOARD	107957	AR	1
8-060-02	PC BOARD	79207	AR	1
8-060-02	PC BOARD	143212	AR	1
8102	PRESS SWITCH	155	AR	1
853JS	PROBE	8098	AR	1
853JS	PITOT PROBE	8758 ,5127	AR	2
83273-1D	SWITCH TEMPERATURE	1459TW, 1451TW	AR	2
9002EN7	MICRO DOOR SWITCH	8624	AR	1
9002EN7	MICRO DOOR SWITCH	8537	AR	1
91547-SOCN-0-300-711-01	VALVE	1501	AR	1
91547-SOCN-2-303-052-04	CONTROLLER OVERSPEED	9901307038161 , 3363 , 3573	AR	3
91547SOCN2-303-026-02	EXCITER IGNITION	919	AR	1
91547-SOCN2-303-026-02K	EXCITER IGNITION	861	AR	1
91652-0	DUMP VALVE	LK0024	AR	1
91652-0	DUMP VALVE	LK8602158	AR	1
917U8/1	LIFT SPOILER SELECTOR	LA890163	AR	1
91762A	HYD PRESS CONTROL VALVE	LK8708188	AR	1
91762/1	PREISION HYDRAULIC	LK8809062	AR	1
98AA1-542	AIR SCREW	434445	AR	1
9300A151-20	CONTROL UNIT	25736	AR	1
965-0476-088	GPS WS COM/MARKII	4536	AR	1
99595-25791-2	ECOLOGY	1486	AR	1
98505-12790-1	PRESSURE SWITCH	0477	AR	1
A069377	HYD FUSE	T005	AR	1
A-848-MLS	CONTACTOR RELAY	CJ-63049	AR	1
A-981MS	CONTACTOR RELAY	CN12788	AR	1
A712RS	CONTACTOR RELAY	CC-86354, NIL	AR	2
AC66816	RELIEF VALVE	41844	AR	1
AC67650	ANTI SKID VALVE	ER085,RQ135,DJ047,UW089	AR	4
AC69377	HYDRAULIC FUSE	982, 966,627	AR	3
AC69377	HYDRAULIC FUSE	879 , 822 , 841	AR	3
ACM28238	CHECK VALVE	DU055	AR	1
ACM28238	CHECK VALVE	DU054	AR	1
ACM28248	CHECK VALVE	CU423	AR	1
ACM28994	CHECK VALVE	148CY,147CY	AR	2
ACM29021	VALVE	DA31	AR	1
ACM30506	HYDRAULIC FUSE	LJ193	AR	1
ACM30506 / MWP3150P.S.1 FLUID TYPE 4	HYDRAULIC FUSE		AR	2
AC65718	SOLENIOD VALVE	DW507 , RQ271	AR	2
AC65716	SOLENIOD VALVE	EU203	AR	1
AHA2331/2	BRAKE	LY052	AR	1
AHA2332/4	BRAKE	YC074	AR	1
AHA2332/2	BRAKE	NX071	AR	1
AHA2331/4	BRAKE	HE217	AR	1
AHM8091 ISS2 CNA18	ANTI SKID TRANSDUCER	A18	AR	1
AIRLITE90	PILOT HEADSET	13M14172	AR	1

AVIBANK53685	RFC ENGINE	NA	AR	1
AVIBANK53686	RFC ENGINE	NA	AR	1
B-345LS	CONTACTOR RELAY	CE-62665, CJ-77742,NIL,CJ83595	AR	4
B-345LS	CONTACTOR RELAY	CD-41333	AR	1
B-345LS	CONTACTOR RELAY	CG-64124 , CL-89281 , CJ-72762 , CJ-11319	AR	4
B01A214272A	AIR FRAME	ALVL188/446	AR	1
B01A214271A	DUCT RELIEF VALVE	DRYL87245, DRYL89527	AR	2
B01A214271A	DUCT RELIEF VALVE	DRYL89539	AR	1
BA500057GB3	REALIFE VALVE	F1823572	AR	1
C589512-0103	E L T	21770E	AR	1
D60151	TRANSDUCER	152336, 150826	AR	2
D60151	TRANSDUCER	124617 , 124612	AR	2
DRG4684C000	HEAT EXCHANGER	578183-3, 2069	AR	2
EA50057-GB3	IN LINE RELIEF VALVE	F0820836, F9012860	AR	2
E37040S	PITOT HEAT MONITOR	E091R	AR	1
E37040D	PITOT HEAT MONITOR	E049/R	AR	1
E37040S	PITOT HEAT MONITOR	E065/R	AR	1
HC324B0104-000	VALVE HYDRAULIC	G85151-3-1	AR	1
HC391H0009-000	PANEL ICE PROTECTION	DH01	AR	1
HC272H0406-000	HYD JACK	2 05 01	AR	1
HC276H0201-002	ROD	37083	AR	1
HC276H0202-006	HYD JACK	5182	AR	1
HC931-B0006000	3 WAY VALVE	FA20939	AR	1
HC931-B0058-000	CHECK VALVE	FB12649, FR75987	AR	2
HC712H0019-000	PIN	NA	AR	2
HC712H0045-000	BUSHING		AR	2
HR6B9-002-UK2	REALIFE VALVE	F27815499,F2825837	AR	2
HP1138200-1	VALVE CONTROL	1021	AR	1
HTE210014	ACTUATOR ROTARY	790GB364	AR	1
HTE210014	ACTUATOR ROTARY	389GB260	AR	1
HTE210014	ACTUATOR ROTARY	786GB132 , M189GB399	AR	2
HTE250076-1	FUEL CONTROL VALVE	M101VBF1290,FR004BH	AR	2
HTE250076-1-1	FLIGHT REFUELING	30010533	AR	1
HTE9526	RELIEF VALVE	180VNR216,R3Q90	AR	2
HTE9531-101	MOTORIZED VALVE	FRO013BB,181NB119	AR	2
HTE9531-101	MOTORIZED VALVE	1089VB103	SVC	1
HTE9635-3	MOTORIZED VALVE	187U8764 , 585VB185 , 387VB123	AR	3
HTE9082	APU FUEL SHUT OFF VALVE	584G8231H	AR	1
HTE9082/1	TEMP MOTOR	382GB324/HR , 586GB256/H	AR	2
HTE9082/1	TEMP VALVE	384GB246/H,184GB211	AR	2
HTE9082/1	TEMP VALVE	381GB299 , 481GB158HR	AR	2
HTE690042 ISS3	PRESSURE SWITCH	615	AR	1
HTE690046	PRESSURE SWITCH	20174	AR	1
HTE690046	PRESS SWITCH	1022	AR	1
HTE2479/3 (HTE9682)	MOTORIZED VALVE	8002	AR	1
HTE4345/2 ISS4A	CHECK VALVE	M108	AR	1
HTE4345/2 ISS4A	CHECK VALVE	M143	AR	1

IU471-001	SIGMA	T698	AR	1
IU471-001	SIGMA	T416	AR	1
IU471-001	SIGMA	T207	AR	1
K93580	OXYGEN INDICATOR	770,2209/05 , 2520/04/82	AR	3
L1330A	FUSE 50,35,130AMPERE		AR	9
M300-1264	RELAY		AR	56
M302-D4A	BALANCE FORCE RELAY		AR	4
M400-1265	RELAY		AR	93
M402-D4A	RELAY		AR	4
M401-D4E	RELAY		AR	1
M401-D4F	RELAY		AR	13
M422-M15-2	BRAKE FAN MOTOR	910921, 479928	AR	2
M422M15	BRAKE FAN MOTOR	870605	AR	1
M422M15-2	BRAKE FAN MOTOR	810213	AR	1
MAP903-001	ISOLATION VALVE	PRVL87148, PRVL8837	AR	2
MFR-81640	TEST SWITCH		AR	1
MXP127	FLIGHT CREW MASK	17569 , 3363 , 4323 , 3362 , 4771	AR	5
MXP127	FLIGHT CREW MASK	13233	AR	1
NC82024 ISS4	DOOR CABLE	NC4205/96	AR	1
NC82027 ISS5	DOOR CABLE	UNK	AR	1
NF00751600-1	PC B WIND SCREEN RHA	128202	AR	1
NF0075/2600	THERMAL CONTROLLER	128262	AR	1
NF0075/2600	THERMAL CONTROLLER	224583	AR	1
P308-45-0102	LIFT SPOILER JACK	CSW140	AR	1
P308-45-0102	LIFT SPOILER JACK	NJX 003	AR	1
P308-45-0102	LIFT SPOILER JACK	NJL 001 , DBP BAE 5110	AR	2
P308-45-0102	LIFT SPOILER JACK	DBP BAE 5107 , DBP BAE 51307	AR	2
P308-45-0202	LIFT SPOILER JACK	AAA05P308	AR	1
P311-45-0002	BAE146 AILERON GROUND GUST DAMPER	A78,A591	AR	2
PV1591C	CONTROL UNIT	1107	AR	1
RD25010	RELAY	FRR8305,UNK,FRR8305/2	AR	3
RD25081	TRANSFORMER NAVIGATION	UNK	AR	1
RSTW10	BUSHING	-	AR	2
SM601BA40A13	CIRCUIT BREAKER	17	AR	1
SMX-649-29616	SECTOR MICROWAVE	374	AR	1
XW25448-1	WIPER BLADE	2314M-191-1	AR	1
WL/0201KID/1	FUEL QUANTITY INDICATOR	C/TT786/C	AR	1
WL/0201KID/1	FUEL QUANTITY INDICATOR	TT5416	AR	1
WL/0201KID/1	FUEL QUANTITY INDICATOR	TT7601	AR	1
WL/0201KID/2	FUEL QUANTITY INDICATOR	TT818,TT685	AR	2
WKA37577	ADAPTER, FIVE WAY	807	AR	1
WKA36682-1	PLUG VALVE	1723	AR	1
WKA36684-2	VALVE WATER BOTTLE	118 ,740	AR	2
TYPE NO EJF101	VALVE TANK	L-42	AR	1